

SKI INSTALLATION INSTRUCTIONS

POLARIS: 2012 & NEWER (PRO & AXYS CHASSIS)
MOUNT KIT #04-B002-3

475 SE 12th St MADISON, SD 57042

www.slydogskis.com

	1: !	REMOVE	OLD SKIS	AND I	DISCARD	OLD	HARDWARE.
--	------	--------	----------	-------	---------	-----	-----------

- 2: INSTALL THE CARBIDES AT THIS TIME.
- 3: INSERT SMALL BUSHINGS INSIDE OF THE SKI AND LARGER BUSHING ON THE OUTSIDE OF THE SKI, THEY FIT VERY TIGHT.
- 4: PLACE RUBBER DAMPENER ON THE SKIS.
 (SEE DETAIL VIEW 1 FOR DAMPENER ORIENTATION)

5: USE REMAINING HARDWARE TO SECURE THE SKIS. (SEE DIAGRAM)

2
DETAIL 1

TEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	77000266	Rubber Dampener	2
2	20010MML	Large Bushing	4
3	20010MMS	Small Bushing	4
4	1138671	M10-1.5 x 130mm Hex Bolt	2
5	1140167	M10-1.5 Hex LockNut	2

