

1-605-256-3075

www.slydogskis.com

SKI INSTALLATION INSTRUCTIONS

ARCTIC CAT: 2012 PRO CHASSIS & NEWER MOUNT KIT #04-B001-3

1: REMOVE OLD SKIS AND DISCARD OLD HARDWARE.

475 SE 12th St

MADISON, SD 57042

2: INSTALL THE CARBIDES AT THIS TIME.

- 3: INSERT SMALL BUSHINGS INSIDE OF THE SKI AND LARGER BUSHING ON THE OUTSIDE OF THE SKI, THEY FIT VERY TIGHT.
- 4: PLACE RUBBER DAMPENER ON THE SKIS. (SEE DETAIL VIEW 1 FOR DAMPENER ORIENTATION)
- 5: USE REMAINING HARDWARE TO SECURE THE SKIS. (SEE DIAGRAM)

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	77000273	Rubber Dampener	2
2	20010MML	Large Bushing	4
3	20010MMS	Small Bushing	4
4	1138671	M10-1.5 x 130mm Hex Bolt	2
5	1140167	M10-1.5 Hex LockNut	2



